


# 10/100 Ethernet Aux I/O



## Network Interface Card Getting Started Guide



Part No. 1.024.1309-01




# 10/100 Ethernet Aux I/O

## Network Interface Card Getting Started Guide

<http://www.3com.com/>

Part No. 1.024.1309-01

---



**3Com Corporation**  
**5400 Bayfront Plaza**  
**Santa Clara, California**  
**95052-8145**

Copyright © 1999, 3Com Corporation. All rights reserved. No part of this documentation may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from 3Com Corporation.

3Com Corporation reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of 3Com Corporation to provide notification of such revision or change.

3Com Corporation provides this documentation without warranty of any kind, either implied or expressed, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. 3Com may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

**UNITED STATES GOVERNMENT LEGENDS:**

If you are a United States government agency, then this documentation and the software described herein are provided to you subject to the following:

**United States Government Legend:** All technical data and computer software is commercial in nature and developed solely at private expense. Software is delivered as Commercial Computer Software as defined in DFARS 252.227-7014 (June 1995) or as a commercial item as defined in FAR 2.101(a) and as such is provided with only such rights as are provided in 3Com's standard commercial license for the Software. Technical data is provided with limited rights only as provided in DFAR 252.227-7015 (Nov 1995) or FAR 52.227-14 (June 1987), whichever is applicable. You agree not to remove or deface any portion of any legend provided on any licensed program or documentation contained in, or delivered to you in conjunction with, this User Guide.

Unless otherwise indicated, 3Com registered trademarks are registered in the United States and may or may not be registered in other countries.

3Com, the 3Com logo, Total Control, Total Control Hub, and Total Control Manager are registered trademarks of 3Com Corporation.

Other brand and product names may be registered trademarks or trademarks of their respective holders.

**YEAR 2000 INFORMATION:**

For information on Year 2000 compliance and 3Com products, visit the 3Com Year 2000 web page:

*<http://www.3Com.com/products/yr2000.html>*

# CONTENTS

---

## 1 OVERVIEW

Contacting 3Com.....	1-1
Document Conventions.....	1-2
Product Description .....	1-3
Product Compatibility.....	1-3

---

## 2 INSTALLATION

Installation Tools.....	2-1
Installation Procedure .....	2-1

---

## 3 NETWORK INTERFACE CARD CABLING


Physical Interfaces .....	3-1
Accessing the User Interface.....	3-2
Connecting for Remote Access .....	3-2
Connecting for Local Access .....	3-2
Connecting for a Software Download .....	3-2

---

## A TECHNICAL SPECIFICATIONS

Trouble Clearing .....	A-1
LAN link integrity LEDs on the NIC .....	A-2
RN/FL LED on the HiPer NMC NAC at power-up.....	A-2
Technical Specifications .....	A-2
Certification .....	A-2
Regulatory Compliance Statements .....	A-3
United States .....	A-3
FCC Part 15 Compliance Statement .....	A-3
Interface Specifications.....	A-3
Console and WAN Port .....	A-3
Console and WAN cable specifications.....	A-3
Ethernet 10Base-T/100Base-Tx Port .....	A-4
Ethernet 10Base-T/100 Base-Tx cable specifications.....	A-4

Current Draw .....	A-4
Environment .....	A-5
Shipping and Storage .....	A-5
Operating.....	A-5
Physical Dimensions .....	A-5



# OVERVIEW

This chapter provides an overview of:

- Contacting 3Com
- Document conventions
- Product description
- Product compatibility

---

## Contacting 3Com

Call the appropriate toll free number listed below for technical support.



*For European countries that do not have a toll free number listed, call +31 30 602 9900.*

Country	Toll Free Number	Country	Toll Free Number
<b>Austria</b>	06 607468	<b>Netherlands</b>	0800 0227788
<b>Belgium</b>	0800 71429	<b>Norway</b>	800 11376
<b>Canada</b>	1800 2318770	<b>Poland</b>	00800 3111206
<b>Denmark</b>	800 17309	<b>Portugal</b>	0800 831416
<b>Finland</b>	0800 113153	<b>South Africa</b>	0800 995014
<b>France</b>	0800 917959	<b>Spain</b>	900 983125
<b>Germany</b>	0800 1821502	<b>Sweden</b>	020 795482
<b>Hungary</b>	00800 12813	<b>Switzerland</b>	0800 553072
<b>Ireland</b>	1800 553117	<b>UK</b>	0800 966197
<b>Israel</b>	0800 9453794	<b>United States</b>	1800 2318770
<b>Italy</b>	1678 79489	<b>All Other Locations (Outside Europe)</b>	1847 7976600

Refer to the Total Control Hub Documentation CD-ROM for more information regarding product warranty.



For information about Customer Service, including support, training, contracts, and documentation, visit our website at <http://totalservice.3com.com>

## Document Conventions

These tables list conventions used throughout this guide.

Icon	Notice Type	Description
	Information note	Information that contains important features or instructions.
	Caution	Information to alert you to potential damage to a program, system, or device.
	Warning	Information to alert you to potential personal injury or fatality. May also alert you to potential electrical hazard.
	ESD	Information to alert you to take proper grounding precautions before handling a product.

Convention	Description
Text represented as a screen display	This <code>typeface</code> represents displays that appear on your terminal screen, for example: <code>Netlogin:</code>
Text represented as <b>commands</b>	<b>This typeface</b> represents commands that you enter for example: <code>setenv TCMHOME directory</code> <i>This guide always gives the full form of a command in uppercase and lowercase letters. However, you can abbreviate commands by entering only the uppercase letters and the appropriate value. Commands are not case-sensitive.</i>
Text represented as <b>menu</b> or <b>sub-menu names</b> .	<b>This typeface</b> represents all menu and sub-menu names within procedures, for example: On the <b>File</b> menu, click <b>New</b> .

---

**Product  
Description**

The 10/100 AUX I/O Ethernet Network Interface Card (NIC) provides the physical link between the Network Management Card (NMC) and other chassis devices. The NIC is also the link between the NMC and the Management Station (MS).

The NIC has these characteristics:

- Provides the interface to the local area network (LAN)
- Provides an EIA RS-232 port (console port) that can be used to configure and manage the NMC
- Provides two auxiliary inputs and two auxiliary outputs on an 8-pin terminal block for alarm event monitoring and triggering
- Provides an EIA RS-232 port that can be used to manage the NMC through a remote SLIP connection

---

**Product  
Compatibility**

The 10/100 AUX I/O Ethernet NIC is compatible with the HiPer NMC Network Application Card (NAC).



# 2

## INSTALLATION

This chapter contains 10/100 Ethernet Aux I/O Network Interface Card (NIC) installation information.

---

### Installation Tools

To install this NIC in the Total Control chassis, you need a #2 Phillips and flat-head screwdriver.

---

### Installation Procedure

To install this NIC:




**ESD:** To reduce the risk of electrostatic discharge (ESD), take proper grounding precautions before handling the NIC.



Install the NIC with or without power applied to the chassis.

- 1 Configure the NIC via jumpers. The NIC should be factory preset to “NMC”. Verify that the two-pin shunt is placed in the “NMC” position.




The 10/100 Ethernet I/O NIC only works behind the HiPer NMC NAC. The jumper should not be changed from the factory setting.


- 2 Select a slot at the rear of the Total Control chassis for installing the NIC.  
Install this NIC in slot: 17




*For managed chassis, slot 17 is reserved for the Network Management Card (NMC) NIC.*




- 3 Use a #2 Phillips screwdriver to remove the safety panel covering this slot.




- 4 Insert the NIC between the slot's upper and lower card guides.



- 5 Slide the NIC into the chassis, until the front of the NIC is flush with the chassis.



- 6 Use a flat-head screwdriver to tighten the screws on the front panel.



- 7 Cover any unused chassis slots with safety panels.
- 8 Install the Network Application Card (NAC) corresponding to this NIC. Refer to the NAC's Getting Started Guide for more information.


# 3

## NETWORK INTERFACE CARD CABLING

This chapter provides information about the physical interfaces of the 10/100 Ethernet Aux I/O Network Interface Card (NIC) and instructions for accessing the corresponding Network Application Card (NAC) through the user interface (UI).

### Physical Interfaces


The 10/100 Ethernet Aux I/O NIC has the following physical interfaces:



Callout Number	Interface Description
1	<p><b>Console Port:</b> EIA RS-232-D DTE Port</p> <p>Connect to this port to access the HiPer NMC's User Interface (UI), or to connect directly to a PC for a software download. See the <i>NMC Configuration Guide</i> for other configuration of this port.</p>
2	<p><b>WAN port:</b> EIA RS-232-D DTE Port</p> <p>Use the WAN port for a SLIP connection to a management station (MS) running Total Control Manager (TCM) or another SNMP program.</p> <p>You can also use this port for a remote modem connection. Refer to the <i>NMC Configuration Guide</i> for more information.</p>
3	<p><b>Ethernet 10/100 port:</b> RJ-45 port</p> <p>Use this port to connect to an Ethernet LAN. This port is a 10base-T/100base-Tx auto-negotiating Ethernet port. It supports full-duplex operation in addition to standard Ethernet.</p>
4	<p><b>AUX I/O ports:</b></p> <p>Currently not used.</p>

## Accessing the User Interface

To access the UI of the corresponding NAC, connect the following cables to the NIC's console port.



Callout	Description
1	RJ-45 connector to NIC's Console Port
2	DB-25 male connector to modem for remote operations
3	DB-25 female-to-female null modem adapter to PC or terminal COM port

### Connecting for Remote Access

Attach the RJ-45 end of the EIA RS-232 cable to the console port and the DB-25 end to a modem. Use an adapter if the modem does not support a 25-pin connector. Dial in to the modem from the remote site.

### Connecting for Local Access

Attach the RJ-45 end of the cable to the console port and the DB-25 end to the provided null modem adapter. Attach the null modem adapter to the PC/terminal's EIA RS-232 interface. Use an adapter if the PC/terminal does not support a 25-pin connector.

### Connecting for a Software Download

Attach the RJ-45 end of the cable to the console port and the DB-25 end to the provided null modem adapter. Attach the null modem adapter to the PC/terminal's EIA RS-232 interface. Use an adapter if the PC/terminal does not support a 25-pin connector. Then follow the directions in the *Software Download Installation Instructions*, located on the Total Control Hub CD-ROM.




# TROUBLE CLEARING AND TECHNICAL SPECIFICATIONS

## Trouble Clearing

This section contains information to help you trouble clear problems that may occur after you first install and power-up a 10/100 Ethernet Aux I/O Network Interface Card (NIC) and a Hiper Network Management Card (NMC) Network Application Card (NAC). Trouble clearing information concerning NMC configuration is located in the *NMC Configuration Guide*.

### LAN link integrity LEDs on the NIC

Two status LEDs, representing link integrity and network activity on the physical layer, are located on the Ethernet 10/100 port:



LED	Status	Meaning
<b>Activity LED</b> (located on the top of the connector)	Off	Port is inactive
	Flashing yellow-green	Port is transmitting and receiving correctly
<b>Link LED</b> (located on the bottom of the connector)	Solid green	Link OK; Connection is established and NIC is receiving valid link pulses
	Off	No connection; NIC not receiving valid link pulses

### RN/FL LED on the HiPer NMC NAC at power-up

This table provides information on trouble clearing problems that may occur at power-up.

If the RN/FL LED is...	Then...	Do this...
Solid green	The condition is normal	No action required.
Solid red	There is a critical failure	Reinstall the NMC according to the instructions in this manual.
Flashing red and green	There is no NIC installed behind the HiPer NMC NAC	Install the NIC. Refer to the appropriate <i>Getting Started Guide</i> .  Note: If the NIC is installed after the NMC, reboot the NMC by removing and reseating the NMC card.
Off	There is no power to the NAC	Make sure the NMC is installed properly. Make sure the chassis is powered on.

## Technical Specifications

### Certification

<b>EMI/RFI</b>	<ul style="list-style-type: none"> <li>■ FCC 15A</li> <li>■ EN55022A</li> <li>■ EN 50082-1</li> <li>■ VCCI, AUSTEL</li> </ul>
<b>Safety</b>	<ul style="list-style-type: none"> <li>■ UL 1950</li> <li>■ C-UL</li> <li>■ EN 60950</li> </ul>



**Regulatory  
Compliance  
Statements**

**United States**

***FCC Part 15 Compliance Statement***

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

**Interface  
Specifications**

**Console and WAN Port**

<b>Electrical specification</b>	EIA RS-232-D standard
<b>Connector</b>	RJ-45, 8-position modular jack
<b>Configuration</b>	Data Terminal Equipment (DTE)
<b>Transmission method</b>	Unbalanced RS-232, 1-stop bit, no parity
<b>Transmission rate</b>	57.6 Kbps maximum

**Console and WAN cable specifications**

<b>Wire type</b>	Belden 9538 or equivalent, 8-conductor, shielded
<b>Max cable distance</b>	50 ft. (15 m)
<b>Cabling</b>	8-position modular jack to DB-25 (IBM AT pinout)
<b>Nominal direct current resistance</b>	
<i>Center conductor</i>	24-gage (7 strands, 32-gage) 0.61 mm diameter 23.7 ohms/1000 ft. (77.8 ohms/km)
<i>Shield</i>	15.5 ohms/1000 ft. (50.9 ohms/km)
<i>Outside diameter</i>	0.265 in (6.73 mm)
<i>Capacitance between conductors</i>	30 picofarads/ft. (98 picofarads/m)

### Ethernet 10Base-T/100Base-Tx Port

<b>Data transfer rate</b>	10/100 Mbps (auto-negotiated)
<b>Connector</b>	8-position modular jack (Stewart 88-360808 or equivalent)
<b>Accessing scheme</b>	CSMA/CD (Carrier Sense Multiple Access with Collision Detection)
<b>Topology</b>	Star-wired hub (using multiport repeater)
<b>Maximum nodes</b>	Limited only by repeater used
<b>Transmission medium</b>	Unshielded twisted pair (UTP) <b>10Base-T:</b> Type CAT3 or CAT5 (CAT5 recommended) <b>100Base-Tx:</b> Cable type CAT5 only
<b>Network lobe distance</b>	100 m (328 ft.) suggested maximum. Longer cabling can be used at the expense of reduced receiver squelch levels.

### Ethernet 10Base-T/100 Base-Tx cable specifications

<b>Wire type</b>	0.5 mm or 24 AWG twisted pairs
<b>Max cable distance</b>	100 m (328 ft.) with standard receiver squelch levels
<b>Cable loss</b>	67 dB/1000 ft@100 MHz
<b>Characteristic impedance</b>	85-115 ohms
<b>Propagation delay</b>	± 5.7 nanosecond/m
<b>Cabling</b>	RJ-45 plug to RJ-45 plug straight through for multiport repeater applications.

**Current Draw** +5.2 VDC @ .6mA typical maximum



*Typical maximum refers to the maximum current draw under most typical configurations.*

**Environment Shipping and Storage**

<b>Temperature:</b>	-25 to 75° C, -13 to 167° F
<b>Relative Humidity:</b>	0 to 100%, Non-condensing

**Operating**

<b>Temperature</b>	0 to 40° C, 32 to 104° F
<b>Relative Humidity:</b>	0 to 95%, Non-condensing

**Physical Dimensions**

	<b>Inches</b>	<b>Centimeters</b>
<b>Length:</b>	5.30	13.46
<b>Width:</b>	0.79	2.00
<b>Height:</b>	6.90	17.53



3Com Corporation  
5400 Bayfront Plaza  
P.O. Box 58145  
Santa Clara, CA  
95052-8145

©1999  
3Com Corporation  
All rights reserved  
Printed in the U.S.A.

Part No. 1.024.1309-01